


Classroom Technology Quick Start Guide

To use the projector, please turn it on by pressing the on button located on the provided remote control.

Plug the ClickShare button into a USB port on a laptop. Click open to view files and double click the ClickShare icon that reads ClickShare for Windows.





Please wait for the button to communicate with the base. Once the button quits flashing a white light, it will become solid white. You may now press the button to send the laptop to the projector.



To disconnect, please press the button and close the software. You can now unplug the button from your laptop and turn off the projector.